

FIB-R-DOR EXISTING WALL FRAME INSTALLATION

1


ASSEMBLE FRAME
PER
DETAILS ON PAGE #1

2




SLIDE ASSEMBLED FRAME INTO EXISTING OPENING.

3




PLUMB AND LEVEL JAMB. SQUARE CORNERS. SLIDE PLASTIC SHIMS BETWEEN JAMB AND WALL UNTIL JAMB IS SNUG.

4




INSERT $\frac{3}{8}$ " MASONRY BIT INTO HOLES PROVIDED IN FRAME. DRILL BLOCK WALL DEEP ENOUGH FOR 4" LONG ANCHOR SCREWS.

5




INSERT MASONRY SCREWS AND TIGHTEN UNTIL FRAME IS SECURE.

6



TRIM AWAY EXCESS SHIM WITH A SHARP WOOD CHISEL.

7



CAULK JOINT BETWEEN FRAME AND WALL WITH SILICONE SEALER.

8

HANG DOOR AND INSTALL HARDWARE.